

# Acer LCD Monitor Quick Start Guide (QSG)

## Important safety instructions

Please read the following instructions carefully.


- To clean the LCD monitor screen:
  - Turn off the LCD monitor and unplug the power cord.
  - Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
- Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage it.
- Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.
- Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature.
- Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to 140° F). Storing the LCD monitor outside this range may result in permanent damage.
- Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:
  - Monitor-to-PC signal cable is frayed or damaged.
  - Liquid spills onto the LCD monitor or the monitor is exposed to rain.
  - The LCD monitor or case is damaged.

## Attaching the monitor to the base

- Remove the monitor from the packaging.
- Attach the footstand to the base. (for selected models).
- Turn clockwise to lock. Ensure that the base is locked onto the stand. (for selected models)
- Secure the base to the stand by turning the screw using the integrated tab or a suitable coin. (for selected models)

## Connecting your monitor to a computer

- Turn off your computer and unplug your computer's power cord.
- Connect the signal cable to the DVI-D (optional) and /or DP (optional) and/or HDMI/MHL (optional) input socket of the monitor, and the DVI-D (optional) and/or DP (optional) and/or HDMI/MHL (optional) output socket of the graphics card on the computer. Then tighten the thumbscrews on the signal cable connector.
- Connect the USB Cable(Optional)  
Connect the USB 3.0 cable to port for fast charge.  
Connect the USB 3.0 cable to port.
- Optional: Connect the audio input socket (AUDIO IN) of the LCD monitor and the line-out port on the computer with the audio cable.
- Insert the monitor power cable into the power port at the back of the monitor.
- Plug the power cords of your computer and your monitor into a nearby electrical outlet.








## FreeSync :

It can allow a FreeSync supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.



## External controls

1&2	Power button	Turns the monitor on/off. Blue indicates power on. Amber indicates standby/ power saving mode.
3	Function key 	<ol style="list-style-type: none"> <li>Press to view Main page. Press again to enter Volume adjustment function.</li> <li>When the Function Menu is active, press this key selected or move to the next function.</li> </ol>

4	Function key 	a. Press to view Main page.Press again to enter Input select function. b. When the Function Menu is active, press this button selected or move to the previous function.
5	Function key 	a. Press to view Main page.Press again to enter next function in the Function Menu. b. When the Function Menu is active, this button will enter a selection in the OSD.
6	Function key 	a. Press to view Function Menu.Press again to activate the Overdrive function and set it to either Normal or Extreme mode. b. When the OSD menu is active, this button will act as the exit key (exit OSD menu).
7	Function key 	a. When the Main page is active,Press to trigger the Game mode control b. When the Function Menu is active, press to select scenario mode.

For displays with glossy bezels the user should consider the placement of the display as the bezel cause disturbing reflections from surrounding light and bright surfaces.

## Regulations and safety notices

### FCC notices

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

### CE declaration of conformity

Hereby, Acer Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of EMC Directive 2004/108/EC, Low Voltage Directive 2006/95/EC, and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

### Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with EMC regulations.

### Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

### Caution

Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.  
In order to prevent damage to the monitor, do not lift the monitor by its base.

### Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Notice: Canadian users

CANICES-3(B)/NMB-3(B)

## Disposal of waste equipment by user in private household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

## SPECIFICATION

LCD Panel	Driving system	TFT Color LCD
	Size	29"W (73cm)
	Pixel pitch	0.263mm(H) x 0.263mm(V)
	Brightness	300cd/m <sup>2</sup> (Typical)
	Contrast	100,000,000:1Max. (ACM)
	Viewable angle	178° (H) 178° (V) (CR=10)
	Response time	4ms (G to G)
	Panel Type	In-Plane Switch
	Video	Digital Interface
	H-Frequency	HDMI&MHL:15-75KHz DP:99-99KHz DVI:30-99KHz
	V-Frequency	HDMI&MHL:23-76Hz DP:48-75Hz DVI:56-76Hz
Display Colors		16.7M Colors
Dot Clock		330MHz(DVI)300MHz(DP)300MHz(HDMI1.4/MHL2.0)
Max. Resolution		DVI:2560x1080@60Hz HDMI/MHL 2.0: 2560x1080@60Hz, 1920x1080@60Hz DP: 2560x1080@75Hz,2560x1080@60Hz
Plug & Play		VESA DDCCI/DDC2B
Energy Efficiency Class		C
*Annual Energy Consumption		68 (kWh) (for HDMI-input Model)
Power consumption @200cd/m <sup>2</sup>	ON Mode	36.3W(typ.)
	Sleep Mode	0.45W(typ.)
	Off Mode	0.4W(typ.)
Input Connector		DVI-DL 24pin (Only Dual-Input Model) HDMI/MHL (Only HDMI/MHL Model) DP (Only DP-Input Model) USB Hub / USB3.0 x 4 (Only USB Hub Model)
Input Video Signal		Digital signal (Only Dual-Input Model) DP signal (Only DP Model) HDMI/MHL signal (Only HDMI/MHL-Input Model)
Speakers		2W x 2(Only Audio-Input Model)
Maximum Screen Size		Horizontal:673mm Vertical:284mm
Power Source		100-240V~, 50/60Hz
Environmental Considerations		Operating Temp: 5° to 35°C Storage Temp: -20° to 60°C Operating Humidity: 10% to 85%
Dimensions		700 (W) x 374~524 (H) x 245 (D)mm
Weight (N. W.)		8.31kg Unit (net)

Mechanism spec		Tilt: -5° to +35° (Only at the highest point can 35 degrees of recline be offered for the angle of elevation) Swivel: -60° to +60° Height adjustment: 150 mm Pivot: Yes Detachable foot stand: Yes (by Release button)	
External Controls:	Switch / Buttons	Power Button Input switch Volume	Over drive Game mode Main Menu OSD Page Right/Left
	Functions	Black level Blue Light ACM Super Sharpness Gamma Color Temp sRGB mode 6-axis Hue 6-axis Saturate Language OSD Timeout	Refresh rate num Transparency Game mode Aim point Input OD HDMI Black level Wide Mode DDC/CI Quick start mode Reset Power-off USB charge
* All specifications are subject to change without notice.			

Find manuals and other documents for your Acer product on the official Acer support website.

\*Annual energy consumption is calculated using the typical power consumption 4 hours per day, 365 days per year.